



How to Measure for Sliding Fly Screens for Windows

Using the image on the next page you will be able to confidently measure your windows so that you can place an order for the sliding fly screens.

The image shows a typical window configuration of separate side openers and a fixed pane in the centre with a trickle vent at the top. The sliding fly screens are designed to fit inside the window reveal away from the handles.

Reveal installation image shows where the measurements would need to be taken.

A - full width from wall to wall, measure top middle and base and use the narrowest measurement for the overall width.

B - again it is the full height measurement taken in 3 different positions, taking the smallest measurement.

We advise to allow a tolerance on your measurements so you can manoeuvre the frame if necessary, any small gaps can be covered with decorators caulk.

OPTION 1 - REVEAL INSTALLATION

